



<p>10.F-0030</p> <p>6V 12V 24V 36V 48V</p> <p>TESTE DE BATERIA E TESTE DE CIRCUITOS ELÉCTRICOS</p>	<p>10.F-0090</p> <p>12V 24V</p> <p>TESTE DE BATERIA/ALTERNADOR FERVE</p>	<p>10.F-0091</p> <p>12V</p> <p>TESTE DE BATERIA/ALTERNADOR FERVE</p>	<p>10.F-0813</p> <p>12V</p> <p>TESTE DE BATERIA/ALTERNADOR FERVE</p> <p>24 Ah 100 Ah</p>
<p>10.F-0814</p> <p>12V</p> <p>TESTE DE BATERIA/ALTERNADOR</p> <p>32 Ah 190 Ah</p>	<p>45.BT002</p> <p>AGM GEL</p> <p>6V 12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V E 24V</p>	<p>45.BT222</p> <p>12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V</p>	<p>45.BT282</p> <p>AGM EFB GEL</p> <p>12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V</p>
<p>45.BT501</p> <p>AGM EFB GEL</p> <p>6V 12V</p> <p>TESTE DE BATERIA COM IMPRESSORA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V/24V</p>	<p>45.BT400</p> <p>AGM EFB GEL</p> <p>12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V E 24V</p>	<p>45.BT797</p> <p>AGM GEL</p> <p>6V 12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V E 24V</p>	<p>45.BT900</p> <p>AGM EFB GEL</p> <p>12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V E 24V</p>
<p>45.OCV5</p> <p>6V 12V 24V</p> <p>VOLTIMETRO E TESTE DE BATERIA/ALTERNADOR DHC</p>	<p>45.RT003</p> <p>AGM EFB GEL</p> <p>6V 12V</p> <p>TESTE DE BATERIA DHC TESTE DE SISTEMAS ELÉCTRICOS 12V E 24V</p>		
<p>10.F-0705</p> <p>6V 12V</p> <p>CARREGADOR BATERIA FERVE DE 1.5/3 AMPERES</p> <p>9Ah 45Ah</p>	<p>10.F-0903</p> <p>AGM GEL</p> <p>12V</p> <p>CARREGADOR BATERIA FERVE DE 3 AMPERES</p> <p>17Ah 45Ah</p>	<p>10.F-0908</p> <p>AGM GEL</p> <p>12V</p> <p>CARREGADOR BATERIA FERVE DE 5/10 AMPERES</p> <p>24Ah 140Ah</p>	<p>10.F-2201</p> <p>6V 12V</p> <p>CARREGADOR BATERIA FERVE DE 2 AMPERES</p> <p>4Ah 45Ah</p>
<p>10.F-2507</p> <p>AGM GEL</p> <p>12V</p> <p>CARREGADOR BATERIA FERVE DE 7 AMPERES</p> <p>14Ah 230Ah</p>	<p>10.F-2512</p> <p>AGM GEL</p> <p>12V</p> <p>CARREGADOR BATERIA FERVE DE 3,8/12 AMPERES</p> <p>12Ah 360Ah</p>	<p>45.AE1000E</p> <p>AGM EFB GEL</p> <p>12V</p> <p>CARREGADOR BATERIA DHC DE 1.5/10 AMPERES</p> <p>30 Ah 200 Ah</p>	<p>45.AE500E</p> <p>AGM GEL</p> <p>12V</p> <p>CARREGADOR BATERIA DHC DE 5 AMPERES</p>



<p>23.161089</p>  <p>TRANSFORMADOR DE 12V PARA 220V/240V Corrente máxima – 1500W   Corrente contínua – 600W</p>	<p>31.MPD1</p>  <p>TRANSFORMADOR DE 24V PARA 12V Corrente – 3A</p>	<p>31.MPD2</p>  <p>TRANSFORMADOR DE 24V PARA 12V Corrente – 20A</p>	<p>94.E3112</p>  <p>TRANSFORMADOR DE 12V PARA 230V Corrente máxima – 3000W   Corrente contínua – 1700W</p>
<p>97.K2979</p>  <p>TRANSFORMADOR DE 24V PARA 12V Corrente – 240W</p>	<p>99.PV6S</p>  <p>TRANSFORMADOR DE 24V PARA 12V Corrente máxima – 10A   Corrente contínua – 6A</p>	<p>99.PV12S</p>  <p>TRANSFORMADOR DE 24V PARA 12V Corrente máxima – 18A   Corrente contínua – 12A</p>	<p>99.PV18S</p>  <p>TRANSFORMADOR DE CORRENTE DE 18/21 AMPERES Corrente máxima – 18A   Corrente contínua – 21A</p>
<p>10.F-0402</p>  <p>GARRAS ISOLADORAS BOCA CROCODILO (JOGO)</p>	<p>10.F-0416</p>  <p>BUSCA POLOS</p>	<p>10.F-0416-24</p>  <p>BUSCA POLOS</p>	<p>10.F-0425</p>  <p>DENSIMETRO PARA BATERIAS</p>
<p>10.F-1707</p>  <p>PINÇA AMPERIMÉTRICA COM FUNÇÕES DE MULTÍMETRO 0 a 1000A   0 a 1000V</p>	<p>23.210977</p>  <p>MULTÍMETRO DIGITAL</p>		